

AudionET

ART

Aligned Resonance Transport

Owner's Manual

Owner's Manual

The Audionet-Team would like to congratulate you for purchasing the 'ART'.

We recommend to read the owners manual very carefully so you are able to use all the features of the 'ART' and nothing could detract from the music experience.

Included Included in the package are:

- one transport/player Audionet 'ART'
- one remote control 'ART'
- one low resonance stabiliser made of black POM
- one standard power cord.

Please do only transport the 'ART' within the included package. Never leave a CD or the stabiliser in the 'ART' while transporting.

The ART

‘ART’ means Aligned Resonance Transport. Constructing, building and designing the ‘ART’ has been characterised by the principles of analog transport techniques.

‘ART’ is a direct driven mass transport and uses a magnetic stabiliser for smooth rotation of the Compact Disc.

The ‘ART’s’ base consists of a heavy granite stone plate weighing ten kilograms on which the electronic components and the clock circuit are mounted floating as well. The housing is made of a wooden top coated with grey synthetics (NEXTEL) and a 2mm steel chassis that benefits of the resonance defeating mass of the granite plate for stability and smooth performance.

‘ART’s’ weight is approx. eight teen kilograms. The clock generator is mounted floating as protection from resonances to provide a maximum of independence of the internal clock from outer noise sources. As a result ‘clock jitter’ is avoided at the root.

The pick up unit is mounted within a 5mm thick mill-cut aluminium plate and fixed by high tension polyester straps within the wooden top.

Display The display of the ‘ART’ is a vacuum fluorescent display that is emitting a red light. In rooms with low ambient light best results will be achieved. The display will inform you about the current state of the ‘ART’ i.e. the track number and the time position of the current track in minutes and seconds etc

Care Please allow the ‘ART’ to adapt to the climatic conditions at your room after transport. As known for every optical device cold and humidity can lead them covered in condensation. Leave the top of the ‘ART’ open for several hours before switching on the first time after transport.

Please always use a soft, lint-free cloth for cleaning the ‘ART’.

Installation und Anschluß

Placing the ART

The 'ART' should be placed onto a high quality rack or stable table. Avoid exposure to direct sunlight. Do not place the 'ART' close range to loudspeakers or at a corner of the room because in this places the maximum sound energy is to be found.

Audionet 'ART' has to be placed horizontal for achieving the optimal sound results. Please check this using a spirit-level.

Connecting

Use the included power cord to connect the power socket to your wall socket. As being a CLASS I device the 'ART' needs to be earthed.

Internally the 'ART' has separate power supplies for the digital and the analog section each using two 50VA toroid transformers with several voltage stabilisers and fast discrete voltage regulators for a clean power supply of the transport unit and the D/A conversion unit.

Analog outputs

The analog outputs can be found at the back panel of the 'ART'. They provide the music in analog format.

Connect your 'ART' to a pre or main amplifier using high quality cinch connections.

The digital to analog conversion unit is equipped with a digital signal processor (DSP) which is used for oversampling filter calculations. You have the choice between two distinguished digital filters. Use the switch called 'digital filter' at the back panel.

With the switch being in position '**Audionet**' a digital filter will be calculated with short rush in time and long decaying. This has the effect of a short transient time though achieving an excellent amplitude and phase linearity up to 20kHz.

While in position '**Lagrange**' the impulse response of the digital filter is symmetrically. Transient and decay time are both very short leading to a frequency response with a slight amplitude degrading above 16kHz.

We recommend to chose the appropriate filter due to individual listing preferences.

Digital outputs

The output panel of the 'ART' offers you all important digital output standards for tonal relevance.

You have the following possibilities to connect a digital to analog converter:

- RCA: Cinch connection coaxial cord 75 Ohms

- AES / EBU: Balanced connection 110 Ohms

- BNC: BNC connection with coaxial cord 75 Ohms

The outputs are electrically independent towards each other providing the opportunity to compare different cords easily.

In case of connecting an external digital to analog converter please ask your dealer for a high quality digital cord.

Using this cord you connect the 'ART' (digital outputs) with your D/A converter (digital inputs). The position of the switch signed 'digital filter' at the back panel does not interfere with the digital data stream at the digital outputs.

If you are using the 'ART' only as CD-Player , i.e. using only the analog outputs, you can completely switch off the digital outputs by putting the switch 'Outputs' into the position 'off'. This avoids sending out high frequency interferences leading to a better sound.

Operating

Now you switch on the 'ART' by pushing the 'Power'- button at the left of the front panel. The display at the front lightens up and shows 'disc'.

Push the top to the back and put a CD onto the spinning axis of the ART'. Fix it with the provided stabiliser. Then close the top and the 'ART' will read automatically the information track of the CD and displays number of tracks and total playing time.


You can now start playback with the remote control or the 'Play' button at the front panel

Remote control

You can comfortably control the Audionet 'ART' at your listening position with the provided IR remote control. The batteries are to be found beneath a removable plate at the back side. Two batteries of the type 'MIGNON' are used.

The following functions are accessible with the corresponding buttons of the remote control:

1. dim: to control the brightness of the display (four levels).
2. 0...9: use buttons to select and play back a title directly.
3.): starts playback immediately. Pushing this button while playback restarts the actual track at its beginning.
4. |<<, >>|: skip to the next or previous title. Also be used to select title to start playback.
5. <<, >>: press this buttons to fast-reverse/fast-forward the play position.

6. : Pause. Press again to resume playback at current position.
7. : press to stop playback. This button is also used for deleting programs.
8. time : remaining time of current track / entire CD.
9. edit : selects tracks according to selected length of tape (see appendix).
10.  : repeats track / program / CD.
11. clear : use to delete selected titles from a program.
12. recall : display the tracks in their programmed order.
13. mem : toggle program and continues playback.
14. rand : toggle shuffle and continues playback.
15. ams : automatically plays back the first part of each track for ten seconds.
16. a - b: used to set starting and stopping point of a passage for repeated playback.

Remote controlled function EDIT:

Simple edit This operation fits tracks into a specified length while keeping the tracks in their original order.

1. Press 'edit' button in stop mode to light up 'edit' indicator. The tape recording time display (90 min.) appears.
2. Specify the recording time of the tape used using the numeric buttons (0..9). The tracks fitting on tape side A are indicated by bars above and the tracks to fit on tape side B are indicated by bars below the track number.
3. Press 'play' button. The 'peak' indicator lights up and the automatic peak level search operation starts from track number 1. After the auto peak level search of the last track has finished, the passage of about four seconds centred around the peak position will be played four times. Adjust the recording level of the cassette deck during this period. After the peak passage has played four times, the 'ART' enters the pause mode.
4. Press the 'pause' button to start edit play for tape side A. After the edit play for tape side A has been completed the 'ART' automatically enters pause mode.
5. To start play for side B press the 'pause' button again.

Program edit This procedure allows you to record tracks in any desired order while fitting tracks into a specified tape length.

6. Program tracks in the order you like. The rest of the program edit procedure is the same as steps 1 to 5.

Tuning

Nowadays interested listeners experienced tonal differences in using different analog, digital and power cords. In order to increase the value of your 'ART' you have the opportunity to use high performance signal cords. We strongly recommend using them. Also the musical experience is influenced by the use of high quality power cords and power supply filters. The possibilities are not limited.

Audionet offers you the right power cord to increase the sound of your 'ART'. This power cord has a wide diameter, shielded against high frequency influences and has a high immunity to microphonic influence. You can purchase this power cord called 'Audionet **APC**' (Audionet Power Cord) at your local Audionet dealer.

Precautions

- Prevent children playing with plastic bags!
- Please store and operate this unit in a dry room at reasonable room temperature!
- Avoid moisture or any liquid to get into this unit!
- Set up this unit in a free position. Do not cover the top!
- Do not open the case! No user serviceable parts inside.
- Unauthorised opening voids warranty!
- Do not short-circuit the output terminals!

**Engineered and produced by:
Idektron GmbH & Co. KG, Herner Str. 299, Gebäude 6, 44809 Bochum
www.audionet.de
kontakt@audionet.de**